

| DVB-Device | DVB-T | DVB-C | DVB-S | Type / Note |
|--|-------|-------|-------|---|
| Terratec Cinergy HT Express (DVB-T) | X | | | ExpressCard 34 |
| Terratec Cinergy S2 PCI HD, inkl. CI | | | X | PCI-Card , DVB-S2, Manual configuration in window "Settings" → Set capture to „None“ |
| Hauptage WinTV NOVA-T digital terrestrial TV Stick | X | | | USB2-Stick |
| Hauptage WinTV-NOVA-HD-S2 | | | X | PCI-Karte, DVB-S2, Manual configuration in window "Settings" → Set capture to Hauptage ..., deactivate Checkbox „8VSB Modulation for DVB-S2“ |
| Pinnacle PCTV DVB-T-Stick Solo | X | | | USB2-Stick |
| Pinnacle PCTV Dual Sat Pro PCI | | | X | PCI-Card |
| TechniSat SkyStar HD 2 SAT | | | X | PCI- Card |
| TechniSat SkyStar USB 2 HD CI | | | X | USB-Box |